

## Weed Puller Instruction Manual



After Sales Support

Call 0871 911 7031

Email

[customerservice@gardengearonline.co.uk](mailto:customerservice@gardengearonline.co.uk)

Product Code: G3967

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from date of purchase

## General information and safety warnings

- Remove all packaging and make sure that the product is intact. Do not leave packaging materials like bags and staples within the reach of children and pets.
- Read through these instructions fully before using the product.
- Regularly inspect it for signs of wear.
- Store in a cool, dry place away from direct sunlight.
- Do not use the product for anything other than its intended use.
- Do not attempt to repair, disassemble or modify the product.
- Do not let children play with this product.
- Regularly clean the steel prongs to keep in a good working order.
- Not suitable for commercial purposes.

## Description of parts



## Instructions for use

1. Place the weed puller directly over the weed.
2. Push down using your foot on the foot pad so it is flat against the ground.
3. Loosen the weed by moving the weed puller gently from side to side.
4. When the weed is loosened, lever the weed puller out of the ground.
5. Remove the weed from the tool by sliding the weed release handle downwards. You can also remove the weed by pushing down on the release pedal with your foot.
6. If weeding on a lawn, fill the hole with fresh compost to encourage new grass growth.
7. Repeat process to remove further weeds.



## Cleaning and maintenance

1. After each use, clean the steel prongs with a soft damp cloth and allow to dry naturally.
2. Once a year, apply a small amount of lubricant oil to all moving parts.

## GUARANTEE

### IMPORTANT

**Please do not return this product without first calling the Customer Service number below:  
0871 911 7031\***

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase.

Register your product for an extended 2-year warranty by visiting our website [www.gardengearonline.co.uk](http://www.gardengearonline.co.uk). The product must be registered, along with your contact information, within 30 days of purchase. For full terms and conditions please visit our website.

This guarantee does not affect your statutory rights. If your product fails due to a defect in material or workmanship during this period, please return it to the place of purchase. Normal wear and tear is not covered under the guarantee.

Any guarantee is invalid if the product has been misused or subject to neglect or an attempted repair other than by our own service centre.

Due to continuous product improvement, we reserve the right to change the product specification without prior notice.

**After Sales Customer Service:** Branded Garden Products Ltd, Premier House, Hortonwood 7, Telford, TF1 7GP

Telephone: 0871 911 7031\*

E-mail [customerservice@gardengearonline.co.uk](mailto:customerservice@gardengearonline.co.uk)

Please retain for future reference.  
Colours and contents may vary.