



Zero Gravity Chair Instruction Manual



After Sales Support
Call 0871 911 7031
Email
customerservice@gardengearonline.co.uk
Product Code G0880 G0881 G0882
G0883 G0884 G3725 G3726 G3727 G3728
G3729

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from date of purchase

For correct usage, please read these instructions carefully before first use and store in a safe place for future reference.



INTRODUCTION

Congratulations

You have made an excellent choice with the purchase of this quality Garden Gear product.

By doing so you now have the assurance and peace of mind which comes from purchasing a product that has been manufactured to the highest standards, performance and safety.

We want you to be completely satisfied with your purchase, so this Garden Gear product is backed by our full 12 month manufacturers guarantee and an outstanding after sales service through our dedicated Helpline.

Register your product for an extended 2-year warranty by visiting our website www.gardengearonline.co.uk. The product must be registered, along with your contact information, within 30 days of purchase. For full terms and conditions please visit our website.

We hope you enjoy using your purchase for many years to come.

General information and safety instructions

- Maximum user weight limit: 120kg
- This product has been designed for careful domestic outdoor use.
- To prevent accidents, do not put your hands or fingers under the mechanism to operate the chair.
- Open out onto a flat surface, never on a slope.
- Only the occupant should operate the chair.
- Sit down in the chair slowly.
- To avoid tip-over, do not throw your weight against the back of the chair.
- Move the chair into the reclining position slowly, making sure that no children or pets are close by.
- Do not allow children to play on or around a reclining chair, particularly if it is in an open position.
- Never allow an adult or child to sit on the footrest of the chair.
- Only one person should sit in the chair at any one time.
- When moving your recliner, be sure it is completely closed.
- Not to be used by pregnant women.
- Not suitable for commercial purposes.

Instructions for use

- Hold the top of the backrest and gently pull out the front of the chair until the frame is open and standing firmly on a flat surface.
- Sit in the chair from the front; not from the side.
- You can now adjust the position of the recliner to your desired position.
- Once in the preferred position, use the locking levers under each arm to secure into place.
 - **Please note:** the levers will not completely lock the chair into position, however they will hold in place when sitting or lying normally. They are designed to still allow movement if needed or sitting up out of the chair.

Cleaning and maintenance

- Store indoors or under a suitable furniture cover to protect it from the elements and to prolong the life of the chair. Weather damage is not covered under the manufacturer's warranty.
- The whole chair can be cleaned with a soft cloth using warm soapy water.

**GUARANTEE
IMPORTANT**

**Please do not return this product without first calling the Customer Service number below:
0871 911 7031***

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase.

Register your product for an extended 2-year warranty by visiting our website www.gardengearonline.co.uk. The product must be registered, along with your contact information, within 30 days of purchase. For full terms and conditions please visit our website.

This guarantee does not affect your statutory rights. If your product fails due to a defect in material or workmanship during this period, please return it to the place of purchase. Normal wear and tear is not covered under the guarantee.

Any guarantee is invalid if the product has been misused or subject to neglect or an attempted repair other than by our own service centre.

Due to continuous product improvement, we reserve the right to change the product specification without prior notice.

After Sales Customer Service:

Customer Service Department, Branded Garden Products Ltd, Premier House, Hortonwood 7, Telford, TF1 7GP

Telephone: 0871 911 7031*

E-mail customerservice@gardengearonline.co.uk

Please retain for future reference.

Colours and contents may vary.

*Calls cost 13p per minute, plus your phone company's access charge